



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE:

PRO-YD-FF15004-(ALL COLORS)

Tools Required

10mm Socket wrench/ratchet

Phillips Screwdriver

Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open the hood. Remove the phillips head clip securing the rubber radiator shroud weatherstrip.



2) Peel back the radiator shroud weatherstrip. Remove the three 10mm bolts securing the headlight.



3) Unseat the headlight and remove the turn signal bulb sockets and disconnect the headlight wiring harness.



4) Locate the SPYDER headlight. Install turn signal bulb socket into SPYDER headlight, then connect the SPYDER headlight to the OEM headlight wiring harness.



5) Seat the SPYDER headlight. Reinstall the three 10mm bolts securing the headlight.



6) Replace the radiator shroud weatherstrip, then reinstall the plastic Phillips head clip securing it, then close the hood.



7) Enjoy your new SPYDER headlights.



For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information.
<http://www.youtube.com/watch?v=e0c-GQH6-fQ>

Disclaimer

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to cut down installation time for you. We have no responsibility for improper installation, if you do not know how to install, please have a professional install it.