


## **INSTALLATION GUIDE:**

PRO-YD-FM99-1PC AM and CCFL (ALL COLORS)

## **Tools Required**

Slice connector clips





1) Begin by opening your hood and locating the (2) metal fasteners that secure the head light to the frame. Remove them by pulling up and out, this will release the head light.



3) Next, the halos will need to be connected. Twist the (2) red halo power wires together from the Spyder head light. Next, Taking the parking light socket from the vehicle, locate the Brown wire in the center of the socket. You will need to splice the Red power wires to the brown wire using a Splice connector.





2) Once the metal fasteners are removed the head light can be slid out. Remove the Low/High beam and corner light sockets from the back housing of the head light indicated by the arrows.



4) After the power wires have been connected, twist the (2) Black halo ground wires together from the Spyder head light. Again taking the parking light socket from the vehicle, locate the Black wire on the outer left of the socket. Splice the Black ground wires to the Black harness wire using a Splice connector.



5) Next, remove the Low/High beam clip from the bulb with socket, connect that clip into the Spyder head light harness. Insert and secure the corner parking light into the corner housing of the head light, seat the head light on the vehicle



Congratulations on completing the installation for your new Spyder head lights for the 1999-2004 Ford Mustang.



6) Replace the (2) metal fasteners to secure the head light to the frame of the vehicle and you are done.



For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information. https://www.youtube.com/watch?v=XRRs2GMd508&feature=plcp

## Disclaimer

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to cut down installation time for you. We have no responsibility for improper installation, if you do not know how to install, please have a professional install it.