



# SPYDER

WWW.SPYDERAUTO.COM

## INSTALLATION GUIDE:

ALT-YD-DC96-LED-(ALL COLORS)

### Tools Required

Phillips Screwdriver



#### **\*Please Note\***

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open the tailgate. Remove the two phillips head screws securing the tail light.



2) Unseat the tail light by swinging it outward, like you would open a door.



3) Remove the tail light harness by sliding the red retainer tab free, then disconnecting the harness. Then set the OEM tail light aside.



4) Remove the reverse lamp bulb from your OEM tail light by first removing the socket, then removing the bulb from the socket.



5) Transfer the reverse lamp bulb to the SPYDER tail light, installing the bulb fully into the reverse bulb socket, then reinstall the socket into the SPYDER taillight housing.



6) Before we can seat the tail light we must reconnect the harness. Locate the wiring harness connector on the SPYDER LED tail light and plug it into the OEM wiring harness socket, then slide the red tab to lock the harnesses together.



7) Seat the SPYDER LED tail light.



8) Reinstall the two phillips screws that secure the tail light, then close the tailgate/trunk.



9) Enjoy your new SPYDER LED tail lights.



For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information.  
<http://www.youtube.com/watch?v=3jCRFVAmecc>

## Disclaimer

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to cut down installation time for you. We have no responsibility for improper installation, if you do not know how to install, please have a professional install it.