



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE:

ALT-YD-FF15004-LED(ALL COLORS)

Tools Required

10mm Socket wrench/ratchet

Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open your tailgate and locate the (2)10mm bolts. Using the 10mm socket wrench/ratchet to remove the bolts and set them aside for later.



2) Next, gently pull outwards from the side of the tail light to remove freely. Still attached will be the tail light harness (arrow). Remove both bulb sockets by twisting counter-clockwise. Retain the reverse light bulb and only remove the turn signal bulb from the socket.



3) Once the turn signal bulb has been removed, you can now connect the Spyder harness. Make sure the Positive (red/green) and Negative (black) is properly connected or they will not work. Once this has been done, reinstall the reverse light bulb into the new housing.



4) Next install the tail lights onto your vehicle with your 10mm bolts that you have removed from the beginning. Close your tailgate and enjoy the new set of Spyder LED tail lights.



For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information.
<http://www.youtube.com/watch?v=w0sKYuZVSxo>

Disclaimer

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to cut down installation time for you. We have no responsibility for improper installation, if you do not know how to install, please have a professional install it.