



# SPYDER

WWW.SPYDERAUTO.COM

## INSTALLATION GUIDE:

ALT-YD-JGC99-(ALL COLORS)

### Tools Required

Phillips Screwdriver



**\*Please Note\***

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open the tailgate.



2) Open the tail light access panel by releasing the two tabs.



3) Unseat the OEM tail light.



4) Disconnect the tail light wiring harness. Push up on the red tab to unlock the harness, disconnect the harness and remove the OEM tail light.



5) Remove reverse lamp bulb from the OEM tail light. Never touch exposed bulbs with bare hands.



6) Transfer the reverse lamp bulb to the white and black wire reverse lamp socket of the Spyder tail light. Reinstall the socket, then your Spyder tail light is ready to install.



7) Connect the Spyder tail light harness to the main wiring harness. Then push down on the red tab to lock the harness.



8) Seat the Spyder tail light.



9) Transfer the turn signal bulb to the yellow and black wire bulb socket. Transfer the reverse lamp bulb to the white and black wire bulb socket. Then reinstall the sockets. Now your Spyder tail light is ready to install.



10) Close the tailgate and enjoy your new Spyder tail lights!



**SPYDER**  
WWW.SPYDERAUTO.COM

For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information.

<http://www.youtube.com/watch?v=-yQO6HPceu4>

## Disclaimer

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is a guide only, designed to save you time during the installation process. We take no responsibility and cannot be held liable for improper installation. If you do not know how to install your product or are not comfortable doing it yourself, please seek professional installation.