



# SPYDER

WWW.SPYDERAUTO.COM

## INSTALLATION GUIDE:

PRO-YD-ME00-HL(ALL COLORS)

### Tools Required

10mm Socket wrench/ratchet

*\*Please Note\**

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open your hood to reveal the headlight assembly. In order to unmount the headlight you will need to remove (3) 10mm bolts that hold the headlight in place. The locations are indicated by the red arrows.



2) Once the bolts have been removed, you will need to remove the headlight harness connected to the OEM headlamp, shown here. Once the harness is disconnected, pry the light assembly free.



3) Once the assembly is removed and the harness is disconnected, attach the new Spyder harness to the OEM harness as shown in figure (2), remount the headlight, and reinstall the mounting bolts that were removed in figure (1).



4) Lastly, test the new headlight assembly. Low beam and high beam will only come on individually and will not stay on together. Above is for reference only. Halo LED's require additional wiring; Please refer to our wiring guide at [www.spyderauto.com](http://www.spyderauto.com)



For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information.  
[http://www.youtube.com/watch?v=rqcKOwHX\\_Gs](http://www.youtube.com/watch?v=rqcKOwHX_Gs)

## Disclaimer

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to cut down installation time for you. We have no responsibility for improper installation, if you do not know how to install, please have a professional install it.